## Photoelectric background suppression



## Product Data Electrical Data


Electrical Data			
	DC	AC	
Supply Voltage	10 - 30 V dc	12 - 240 V dc / 20 - 240 V ac	
Voltage ripple	+/- 15%	-	
Reverse polarity protected	Yes	-	
Short circuit protected	Yes		
Current consumption	< 65 mA	< 70 mA	
Output relay	-	1 open / 1 close, 240 V ac / 2 A	
Output transistor	200 mA / 30 V dc	-	

<b>Environmental Data</b>		
Temperature, operation	on	-20 to +55 °C
Sealing class		IP 67
Approvals	ac	CK CE CAN'US
	dc	K <b>(€</b>

Available I	Models					
	Model	Supply Voltage	Output	Time Delay	Sensing Range	
	SPBS 2600 T	10-30 V dc	NPN / PNP	On/Off Delay		
	SPBS 2600	10-30 V uc	INFIN / FINE	-	0 - 0.5  m	
	SPBS 2900 T	12 – 240 V dc	Relay	On/Off Delay	adjustable*	
	SPBS 2900	20 – 240 V ac	IXelay	-		
Diffuse	SPBS 2601 T	10-30 V dc	NPN / PNP	On/Off Delay		
Proximity	SPBS 2601	10-30 V uc	INFIN / FINE	-	0 – 1,5 m,	
(background	SPBS 2901 T	12 – 240 V dc	Relay	On/Off Delay	adjustable*	
suppression)	SPBS 2901	20 – 240 V ac	Relay	-		
	SPBS 2602 T	10-30 V dc	NPN / PNP	On/Off Delay		
	SPBS 2602	10-30 V uc	INFIN / FINE	-	0 - 2 m	
	SPBS 2902 T	12 – 240 V dc	PBS 2902 T 12 – 240 V dc	Polov	On/Off Delay	adjustable*
	SPBS 2902	20 - 240 V ac	Relay	-		
* Note: Meas	ured against matt	white A4 naner				


e: Measured against matt white A4 paper.

### Illustration




### Connection

### Wiring Diagrams



NC: Do not connect wire






NC: Do not connect wire

SPBS 260x Load as NPN





SPBS 290x Relay output

machine guarding stand-alone safety applications.

Connection Wires/Pins				
	Cable	4 pin, M12 plug		
Supply + / Supply ac	Brown	Pin 1 / Brown		
Supply - / Supply ac	Blue	Pin 3 / Blue		
Output NC	Grey	-	( 1 )	
Output NO	Black	-	(• 2 3 4•)	
Output COM	White	-	lacksquare	
Output PNP	Black	Pin 4 / Black		
Output NPN	White	Pin 2 / White	Sensor plug	

#### Website: www.telcosensors.com E-Mail: info@telcosensors.com


Made in Denmark



# Warning This device is not to be used for Personnel Protection in Machine Guarding Safety applications. This device does not include the selfchecking redundant circuitry necessary to allow its use in personnel

## Mounting & Alignment Mounting & Installation

- Position the sensor pointing at the target object.
- Align by moving sensor horizontally and vertically until the output changes when the target object is present (refer to Output Logic table). 2
- Fasten the sensor securely using the enclosed mounting bracket and hardware. Avoid 3



### Adjustments

4

**Output Mode Selection** The output mode can be selected via an integral light/dark switch. Refer to Output Logic table for output mode reference.

Light Operated (N.O.)	Enables the output to be active when there is an object present.	Turn switch to full clockwise position
Dark Operated (N.C.)	Enables the output to be inactive when there is an object present.	Turn switch to full counter clockwise position

Output Logic				
Detection	Output mode	Relay Output	Transistor Output	Output indicator
Object present	Dark operated (N.C.)	CNONC	Open	Off
	Light operated (N.O.)	C NO NC	Closed	On
Object absent	Light operated (N.O.)	CNONC	Open	Off
	Dark operated (N.C.)	C NO NC	Closed	On

### Sensitivity Adjustment

Proceed with the following steps:

- Start with the sensitivity at minimum by turning the potentiometer to full counter clockwise position.
- 2 Place target object in correct position to the SPBS and at the required distance.
- Increase sensitivity slowly from minimum (full counter clockwise) until the yellow output indicator changes. Increase a little further until the red Insufficient Signal indicator is off. If the output has not changed, attempt to move sensor closer to 3 target object and repeat procedure.
- Remove target object. If output changes, the sensitivity is adjusted correctly. If the output does not change then proceed to step 5.
- Place target object in correct position. Decrease the sensitivity by turning the gain 5 potentiometer counter clockwise until the red Insufficient Signal indicator is on.
- Remove target object. If the output changes the sensitivity is adjusted to suit the 6 target but the adjustment is very delicate and not advisable.
- If the output does not change the target object is placed too close to surrounding objects. Please contact your vendor for further information.

## Time Delay Adjustment

T models

The on delay enables output signal to only activate if an object in the detection area is present for the adjusted time period. (In Light operated mode)

The off delay enables output signal to remain activated for the adjusted time period.

The time delay is adjustable between 0 - 10 sec.

On delay	counter clockwise respectively.
Off delay	Increase or decrease off delay by turning potentiometer clockwise or counter clockwise respectively.